



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint	Footprint	Footprint
		5.5" x 7.5"	6.75" x 10.9"	9.45" x 13.6"
ASK PROXIMA	C110		X	
ASK PROXIMA	C160		X	
ASK PROXIMA	C170		X	
ASK PROXIMA	C180		X	
ASK PROXIMA	C410		X	
ASK PROXIMA	C420		X	
ASK PROXIMA	C440			X
ASK PROXIMA	C450			X
BARCO	CV-60			X
BARCO	CV-70			X
BENQ	PB2120		X	
BENQ	PB2140		X	
BENQ	PB2220		X	
BENQ	PB2240		X	
BENQ	PB6100		X	
BENQ	PB6200		X	
BENQ	PB6210			X
BENQ	PB7110			X
BENQ	PB7210			X
BENQ	PB7230			X
BENQ	PB8120			X
BENQ	PB8140			X
BENQ	PB8220			X
BENQ	PB8230			
BENQ	PB8240			X
BENQ	PB8250			X
BENQ	PB9200			X
BENQ	PE5120		X	
BENQ	PE7800			X
BENQ	PE8700			X
BOXLIGHT	CD726C			X
BOXLIGHT	CP320TA			X
BOXLIGHT	CP322I			X
BOXLIGHT	CP634I			X
BOXLIGHT	CP670K			X
BOXLIGHT	CP730E			X
BOXLIGHT	CP740E			X
BOXLIGHT	MP-45			X
BOXLIGHT	MP-57I			X
BOXLIGHT	MP-58I			X
BOXLIGHT	MP-60E			X
BOXLIGHT	MP-63E			X
BOXLIGHT	RAVEN		X	
BOXLIGHT	SD-650Z		X	
BOXLIGHT	SP-10T		X	
BOXLIGHT	XP-8TA		X	
CANON	LV-5220		X	
CANON	LV-7210		X	
CANON	LV-7215		X	
CANON	LV-7220		X	
CANON	LV-7225		X	
CANON	LV-S3		X	



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint	Footprint	Footprint
		5.5" x 7.5"	6.75" x 10.9"	9.45" x 13.6"
CANON	LV-X4		X	
CHRISTE	DS25		X	
CHRISTE	DS30		X	
CHRISTE	LW25U			X
CHRISTE	LX20			X
CHRISTE	LX25		X	
CHRISTE	LX25A		X	
CHRISTE	LX32			X
CHRISTE	LX33			X
CHRISTE	LX37			X
CHRISTE	LX45			X
CHRISTE	ROADSTERS9	Projector does not fit the PMD Series		
CHRISTE	RRLX100	Projector does not fit the PMD Series		
CHRISTE	RRLX65	Projector does not fit the PMD Series		
CHRISTE	RRL6-03	Projector does not fit the PMD Series		
CHRISTE	RRL6-04	Projector does not fit the PMD Series		
CHRISTE	VIVIDWHITE	Projector does not fit the PMD Series		
DELL	2200MP		X	
DELL	2300MP		X	
DELL	3300MP		X	
DELL	4100MP		X	
EIKI	EIP-1		X	
EIKI	EIP-10V			X
EIKI	EIP-25			X
EIKI	LC-180AR			X
EIKI	LC-SB20		X	
EIKI	LC-SD10		X	
EIKI	LC-SE10			X
EIKI	LC-X1100			X
EIKI	LC-X50M			X
EIKI	LC-X70			X
EIKI	LC-XB15		X	
EIKI	LC-XB20		X	
EIKI	LC-XB22		X	
EIKI	LC-XB25		X	
EIKI	LC-XB26		X	
EIKI	LC-XE10			X
EIKI	LC-XG110			X
EIKI	LC-XG210			X
EPSON	CINEMA 200			X
EPSON	CINEMA 200+			X
EPSON	CINEMA 500			X
EPSON	Home 10+			X
EPSON	EMPS1H			X
EPSON	EMP54			X
EPSON	EMP74L			X
EPSON	EMP74			X
EPSON	EMP740		X	
EPSON	EMP745		X	
EPSON	EMP821			X
EPSON	EMP830			X
EPSON	EMP835			X



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint	Footprint	Footprint
		5.5" x 7.5"	6.75" x 10.9"	9.45" x 13.6"
EPSON	EMP7800			X
EPSON	EMP7850			X
EPSON	EMP7900			X
EPSON	EMP8300L			X
EPSON	EMP9300L			X
EPSON	EMPTW500		X	
EPSON	EMPTW10H			X
EPSON	EMPTW200H			X
HITACHI	CP-R555			X
HITACHI	CP-S210			X
HITACHI	CP-S235			X
HITACHI	CP-S318		X	
HITACHI	CP-S335		X	
HITACHI	CP-S420			X
HITACHI	CP-SX5500			X
HITACHI	CP-SX5600			X
HITACHI	CP-X1200			X
HITACHI	CP-X1250			X
HITACHI	CP-X275		X	
HITACHI	CP-X328		X	
HITACHI	CP-X340		X	
HITACHI	CP-X345		X	
HITACHI	CP-X430			X
HITACHI	CP-X445			X
HITACHI	CP-X870			X
HITACHI	CP-X880			X
HITACHI	CP-X885			X
HITACHI	CP-X995			X
HITACHI	ED-X3280		X	
HITACHI	PJTX100			X
HITACHI	HOME-1			X
HP	SB21	X		
HP	VP6111			X
HP	VP6121			X
HP	XP8010			
INFOCUS	C110		X	
INFOCUS	C160		X	
INFOCUS	C170	X	X	
INFOCUS	C180		X	
INFOCUS	C410		X	
INFOCUS	C420		X	
INFOCUS	C440			X
INFOCUS	C450			X
INFOCUS	DP1200X	X	X	
INFOCUS	DP8400X			X
INFOCUS	DP8500X			X
INFOCUS	DP9260 RE			X
INFOCUS	LP120	X	X	
INFOCUS	LP1200			X
INFOCUS	LP240	X	X	
INFOCUS	LP350	X	X	
INFOCUS	LP500	X	X	



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint	Footprint	Footprint
		5.5" x 7.5"	6.75" x 10.9"	9.45" x 13.6"
INFOCUS	LP540		X	
INFOCUS	LP600	X	X	
INFOCUS	LP640		X	
INFOCUS	LP650		X	
INFOCUS	LP70	X	X	
INFOCUS	LP790HB		X	
INFOCUS	LP810		X	
INFOCUS	LP815		X	
INFOCUS	LP820		X	
INFOCUS	LP840			X
INFOCUS	LP850			X
INFOCUS	M2+	X	X	
INFOCUS	PRO AV 9500	Projector does not fit the PMD Series		
INFOCUS	SP4800		X	
INFOCUS	XR-1X		X	
INFOCUS	X1		X	
INFOCUS	X2		X	
INFOCUS	IFCLP20		X	
INFOCUS	IFCLP70		X	
INFOCUS	IFCX1		X	
INFOCUS	IFCX1A		X	
INFOCUS	IFCX2		X	
INFOCUS	SP 4805			X
INFOCUS	SP 5000			X
INFOCUS	SP 5700			X
INFOCUS	SP 7200			X
INFOCUS	SP 7205		X	
JVC	DLAG150CL			X
JVC	DLAHX1U			X
JVC	DLAHX2U			X
JVC	DLAL20U			X
JVC	DLAM2000SC			X
LUXEON	D315M		X	
LUXEON	D412V		X	
LUXEON	D5208HD		X	
LUXEON	D6202A			X
LUXEON	HD250		X	
LUXEON	HD400			X
LUXEON	HD600		X	
LUXEON	L6180HD		X	
LUXEON	L6181HD			X
LUXEON	L713V			X
LUXEON	L720M			X
LUXEON	SX500		X	
LUXEON	SX700			X
LUXEON	SX90		X	
MITSUBISHI	HC2			X
MITSUBISHI	HC3			X
MITSUBISHI	HC2000			X
MITSUBISHI	HC3			X
MITSUBISHI	HC900U			X
MITSUBISHI	S490U			X



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint	Footprint	Footprint
		5.5" x 7.5"	6.75" x 10.9"	9.45" x 13.6"
mitsubishi	SE1U		X	
mitsubishi	SE2U		X	
mitsubishi	SL25U			X
mitsubishi	SL4SU		X	
mitsubishi	SL4U		X	
mitsubishi	X490U			X
mitsubishi	X500U			X
mitsubishi	XD20A		X	
mitsubishi	XD300U		X	
mitsubishi	XD350U		X	
mitsubishi	XD400U		X	
mitsubishi	XD450U		X	
mitsubishi	XD480U		X	
mitsubishi	XD50U		X	
mitsubishi	XD60U		X	
mitsubishi	XD70U		X	
mitsubishi	XL25U			X
mitsubishi	XL30U			X
mitsubishi	XL4U		X	
mitsubishi	XL5900U			X
mitsubishi	XL5950W			X
mitsubishi	XL5U		X	
mitsubishi	XL8U		X	
NEC	GT5000			X
NEC	GT6000			X
NEC	HT1100		X	
NEC	LCDGT1150			X
NEC	LCDGT2150			X
NEC	LT10	X		
NEC	LT170	X		
NEC	HT110			X
NEC	HT410		X	
NEC	HT510		X	
NEC	LT240K			X
NEC	LT245		X	
NEC	LT265		X	
NEC	MT1065			X
NEC	MT1075			X
NEC	VT46		X	
NEC	VT47		X	
NEC	VT470		X	
NEC	VT570		X	
NEC	VT670		X	
NEC	VT770			X
NEC	WT600			X
NEC	XT4100	Projector does not fit the PMD Series		
OPTIMA	EP732		X	
OPTIMA	EP739X		X	
OPTIMA	EP757		X	
OPTIMA	EP758		X	
OPTIMA	EP759		X	
OPTIMA	H30		X	



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint 5.5" x 7.5"	Footprint 6.75" x 10.9"	Footprint 9.45" x 13.6"
OPTIMA	H31		X	
OPTIMA	H56A		X	
OPTIMA	H57			X
OPTIMA	H77			X
PANASONIC	PT-AE200U			X
PANASONIC	PT-AE300U			X
PANASONIC	PT-AE500U			X
PANASONIC	PT-AE700U			X
PANASONIC	PT-D5500U			X
PANASONIC	PT-L6510U			X
PANASONIC	PT-L6600U			X
PANASONIC	PT-L735NTU			X
PANASONIC	PT-L735U			X
PANASONIC	PT-L785U			X
PANASONIC	PT-LB10NTU		X	
PANASONIC	PT-LB10SU		X	
PANASONIC	PT-LB10U		X	
PANASONIC	PT-LB10VU		X	
PANASONIC	PT-LM1U		X	
PANASONIC	PTLM1			
PANASONIC	PTLB10S16		X	
PANASONIC	PTLB10S20		X	
PANASONIC	PTLB10X16		X	
PANASONIC	PTLB10X20		X	
PANASONIC	PTLB10X20W		X	
PANASONIC	PLT735E			X
PANASONIC	PTL735NTE			X
PANASONIC	PTL785E			X
RUNCO	VX-2C	Projector does not fit the PMD Series		
RUNCO	VX-4C	Projector does not fit the PMD Series		
RUNCO	VX-6C	Projector does not fit the PMD Series		
RUNCO	VX-1000D	Projector does not fit the PMD Series		
RUNCO	VX-4000D	Projector does not fit the PMD Series		
RUNCO	VX-5000D	Projector does not fit the PMD Series		
RUNCO	CL-510		X	
RUNCO	CL-710		X	
RUNCO	MBX-1	Projector does not fit the PMD Series		
SANYO	PLC-SW30		X	
SANYO	PLC-SW35		X	
SANYO	PLC-UF15	Projector does not fit the PMD Series		
SANYO	PLC-XC10			
SANYO	PLC-SC10			
SANYO	PLC-XF31	Projector does not fit the PMD Series		
SANYO	PLC-XF35	Projector does not fit the PMD Series		
SANYO	PLC-XF41	Projector does not fit the PMD Series		
SANYO	PLC-XF45	Projector does not fit the PMD Series		
SANYO	PLC-XP51			X
SANYO	PLC-XP55			X
SANYO	PLC-XP55L			X
SANYO	PLC-XT11			X
SANYO	PLC-XT16			X
SANYO	PLC-XU20/A		X	



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint 5.5" x 7.5"	Footprint 6.75" x 10.9"	Footprint 9.45" x 13.6"
SANYO	PLC-XW20A		X	
SANYO	PLC-XU25/A		X	
SANYO	PLC-XU41		X	
SANYO	PLC-XU47		X	
SANYO	PLC-XU50/A		X	
SANYO	PLC-SU50S		X	
SANYO	PLC-XU51		X	
SANYO	PLC-XU55/A		X	
SANYO	PLC-XU56		X	
SANYO	PLC-XU60			X
SANYO	PLV-23			X
SANYO	PLV-70			X
SANYO	PLV-HD10	Projector does not fit the PMD Series		
SANYO	PLV-WF10	Projector does not fit the PMD Series		
SANYO	PLV-Z1			X
SANYO	PLV-Z2			X
SANYO	PLV-Z2			X
SANYO	PLV-Z3			X
SHARP	DT-200			X
SHARP	DT-300			X
SHARP	PG-A10SSL		X	
SHARP	PG-A10X		X	
SHARP	PG-A20X		X	
SHARP	PG-B10S		X	
SHARP	PG-MB60X			X
SHARP	PG-M20S		X	
SHARP	PG-M25X		X	
SHARP	XG-C55X			X
SHARP	XR-1X	X		
SHARP	XV-Z10000U			X
SHARP	XV-Z12000U			X
SHARP	XV-Z200			X
SHARP	XV-Z90			X
SHARP	XV-Z9000U			X
SHARP	XV-Z2000	X	X	
SONY	VPL-CX85			X
SONY	VPL-ES1		X	
SONY	VPL-HS20			X
SONY	VPL-HS3			X
SONY	VPL-HS50			X
SONY	VPL-HS51			X
TOSHIBA	TDPS20U			X
TOSHIBA	TLPT60MU		X	
TOSHIBA	TDP-S9		X	
TOSHIBA	TDP-S20		X	
TOSHIBA	TDP-S21			X
TOSHIBA	TDP-SW20		X	
TOSHIBA	TDP-S80		X	
TOSHIBA	TDP-P6	X		
TOSHIBA	TDP-D2		X	
TOSHIBA	TDP-T80		X	
TOSHIBA	TDP-T90		X	



# Projector Mount Application Guide



Make	Model	PMD .5	PMD-1	PMD-2
		Footprint 5.5" x 7.5"	Footprint 6.75" x 10.9"	Footprint 9.45" x 13.6"
TOSHIBA	TDP-T91			X
TOSHIBA	TW90			X
TOSHIBA	TDP-X4500			X
TOSHIBA	F1		X	
TOSHIBA	TDP-MT200		X	
TOSHIBA	TDP-MT500			X
VIDIKRON	VISION20			X
VIDIKRON	VISION40			X
VIEWSONIC	PJ 1165			X
VIEWSONIC	PJ255D	X		
VIEWSONIC	PJ501			
VIEWSONIC	PJ510			X
VIEWSONIC	PJ550		X	
VIEWSONIC	PJ551		X	
VIEWSONIC	PJ650		X	
VIEWSONIC	PJ750-3			X
YAMAHA	DPX1000			X
YAMAHA	DPX1100	Projector does not fit the PMD Series		
YAMAHA	LPX-500			X
YAMAHA	LPX-510			X